FROGGER™

The Adventures of a Fearless Frog

INSTRUCTIONS

- Move Frog verticelly or horizontally using joystick.
- Object is to safely maneuver Frog to its home within allotted time (Sixty beats on the timer).
- Cross highway without getting run over and cross river without falling in.
- Avoid traffic, deadly snekes, otters, crocodiles, end treacherous diving turtles.
- Points are scored for each safe jump (10 pts); safely arriving home (50 pts); and for beating the timer (10 pts per beat saved).
  Bonus points are scored by escorting home a ledy frog (200); gobbling an insect (200); and safely getting all five frogs home (1000).



TABLE
W87×D67×H64(Adjustable)
(14" color Monitor)

UPRIGHT
W64×D69×H173cm
(20" color Monitor)





Konami®

SEGA®

Sega Enterprises Ltd.
2-12, Haneda 1-chome
Ota-ku, Tokyo 144, Japan
Tel.: (03) 742-3171
Tlx: J22357 SEGASTAR

Gremlin Industries, Inc.
8401 Aero Drive
San Diego, California 92123
U.S.A.
Tel.: (714) 277-8700
Tlx. 9103351621 GREMLIN SDG

Sega Europe Limited
15 Old Bond Street
Mayfair, London W1X 3DB
England
Tel.. 01-409 1286
Tlx. 25512 SEGAUK G